

OZZ Hood Shield Bracket

88967 (black)

Mounting

1. Mount the auxiliary light to the bracket using appropriate hardware.
2. Tighten the bracket using the M8 bolt until securely clamped.
3. Open the hood and position the bracket on the edge of the hood in the desired location.
4. Ensure the rubber gaskets are correctly placed between the bracket and the hood to protect the paintwork.
5. Adjust the bracket so it clamps evenly over both the upper and lower edges of the hood.
6. Check that all bolts are tightened securely and that the bracket is firmly attached before driving.

Figure 01

