

OZZ WB1 P20" 65

88505 (black)

Before installation

1. Before installation, check local laws and regulations, as well as those of any regions your vehicle may travel to, to ensure the auxiliary lights comply with all requirements.
2. Carefully read all installation instructions prior to beginning.
3. Verify that the dimensions and weight of the lamps and devices are suitable for your vehicle, see figure 01.
4. A small amount of internal moisture may occur but will be expelled through the vent after 2-4 operating cycles.
5. Operating Voltage: 10-32V DC.

Mounting

1. Firstly, verify that all the components and accessories are included in the box. Test the lamp before installation.
2. Drill 8.5mm holes for screw placement on the surface where you would like to fix the light.

Figure 01. shows multi mounting options: side bracket and bottom bracket.

Wiring connections & Functions

Black: Ground, -
Red: Flood light, +
Yellow: R65 function by day, +
White: Warning pattern switch and synchronization, +
Blue: Red position light on reflector, +

Wiring harness: 40A, 30A fuse.

Please note!

Do not use the product if the lamp housing or lens is damaged upon removal from the packaging.

Ensure the power is turned off during installation.

Figure 01

