

OZZ WL1 65

88401

Before installation

1. Before installation, check local laws and regulations, as well as those of any regions your vehicle may travel to, to ensure the auxiliary lights comply with all requirements.
2. Carefully read all installation instructions prior to beginning.
3. Verify that the dimensions and weight of the lamps and devices are suitable for your vehicle.
4. A small amount of internal moisture may occur but will be expelled through the vent after 2-4 operating cycles.
5. Operating Voltage: 10-30V DC.

Mounting

1. Firstly, verify that all the components and accessories are included in the box. Test the lamp before installation.
2. Connect black cable to ground (-).
3. Connect red cable to positive (+).
4. To synchronise multiple units (max 8 pcs) connect the yellow cables together and then apply to positive (+) for 1 second, and then release.
5. To switch between day and night mode, apply the yellow cables to positive (+) for 1 second, and then release.
6. Bracket mounting, see figure 01.

Wiring connections & Functions

Red = Positive, +
Black = Negative, -
Yellow: Day/night mode switch/Synchronisation, +

Please note!

Do not use the product if the lamp housing or lens is damaged upon removal from the packaging.

Figure 01

